## INSTALLATION GUIDE

## **T60 SERIES SCULLERY SINKS**

- Your Griffin C60 series Scullery Sink is shipped with the legs unattached.
  Turn your sink upside down on a protected surface and insert the legs completely inside the gussets.
- 2)There is a set screw opening on the gusset into which you insert the 5/16 in. set screw and tighten with an allen wrench. Your set screws are located in a bag tapped to the back side of the backsplash.
- 3) Turn your sink right-side up. For uneven floor surfaces there is an adjustment available in each bullet foot.

